

Have the Coolest Sled on the Snow!



Alan & Tammy Schoen
361 SE Sunrise Drive
Mountain Home, ID 83647

208-587-8584
www.2coolairvents.com
schoen311@roadrunner.com



INSTRUCTIONS FOR INSTALLATION:

- ◇ **AirVents** fit either vertical or horizontal behind the shock on the front of the belly.
- ◇ Hold **AirVents** up and mark and drill rivet holes.
- ◇ Grab a holesaw and drill some holes in the area behind the vent so air can flow through the **AirVents** once installed. Do not cut out the entire panel behind the vent as this area is very vulnerable. Keeping the strength of your bellypan is important since you don't know what you may run over.
- ◇ Use 3/16" black rivets to attach **AirVents** to your stock panel.
- ◇ Enjoy your '**COOL**' sled!



Please contact us with Suggestions or Problems!

Tammy or Alan Schoen
1-208-587-8584 or 1-208-590-1786

schoen311@adelphia.net
www.2coolairvents.com

NOTE: If you get a puncture or tear in your panel, contact us and we can replace the fabric at a nominal cost.